

# Digital Heating Portable PCB Ultrasonic Cleaner 3 L , 1-30 Mins Adjust

# **Basic Information**

Place of Origin: China
Brand Name: Skymen
Certification: CE, RoHS
Model Number: JP-020S
Minimum Order Quantity: 1 pcs
Price: Negotiation

• Packaging Details: Packing size: 360x280x320mm(LxWxH) for

1pcs; packed by box and foam; 36pcs per

CBM

• Delivery Time: In Stock

• Payment Terms: Western Union, L/C, T/T, Paypal

• Supply Ability: 5,000 pcs per month



# **Product Specification**

Ultrasonic Power: 120WHeating Power: 100W

• Tank Size: 240x135x100mm

• Tank Capacity: 3L

Aavailable: Stainless Steel Basket

• Power Supply: 110V/220V

 Highlight: skymen ultrasonic cleaner, ultrasonic bath cleaner



# More Images



# **Product Description**

## PCB Board Digital Ultrasonic Cleaner 1-30mins Adjust

#### Production description:

Digital 3L ultrasonic cleaner JP-020S (With digital timer & heater) SUS304 basket is available 1 year warranty OEM & ODM available



#### JP-020S specifications:

Frequency	40KHz
Material	Stainless steel SUS304
Tank capacity	3.2L
Timer	1-30min, digital timer
Power supply	AC 100-120V, 50/60Hz
	AC 220-240V, 50/60Hz
Ultrasonic power	120W
Heating power	100W, digital heating
Unit size	265x165x220mm( L x W x H )
Tank size	240x135x100mm( L x W x H )
Package size	360x280x320mm( L x W x H )
N.W	3.5kg
G.W	4.5kg

## Features:

- 1. Stainless steel tank has resistance to wear and long work life
- 2. Tank capacity:2L , with digital timer & heater control
- 3. With Stainless steel basket
- 4. Use just tab water , or industrial alcohol and solvent cleaner for more higher cleaning requirement
- ${\bf 5.}\ \ {\bf Industrial\ control\ chip\ microcontroller\ ,\ flexible\ circuit\ boards\ control\ ,\ more\ secure\ \&\ stable}$
- 6. Temperature tunable from 20°C to 80°C
- 7. Certification: CE & RoHS



#### Cleaning methods:

- 1, Method for cleaning contact lenses in the cleaning machine: put in tap water, put a small container in the machine inside the inner liner, a small container of contact lens care solution or saline or, contact lenses placed in a small container, the boot can be cleaned;
- 2, the framework of the glasses cleaning method:
- (1) cleaning method slightly greasy glasses: in the washing machine is put in a few drops of water and detergent, mixing evenly, and then into the glasses, the boot can be cleaned;
- (2) a cleaning method of fingerprint and grease glasses mirror: in the cleaning machine into the water and a few drops of detergent and salt, stirring evenly, and then in the lens is coated with detergent, into the machine liner, boot wash:
- (3) perennial not cleaned, a moldy green stains, glasses cleaning method: in the cleaning machine into the water and a few drops of detergent, salt, vinegar or carbonated beverage mixing evenly, then in the lens is coated with detergent, into the machine liner, boot wash;
- 3, Cleaning method: watch in cleaning machine is put in a few drops of water and detergent, if the scale and then some white vinegar, stirring evenly, put the watch in the small bracket into the washing machine wash tank, boot.

## Free service of Skymen:

Free for inquiry before purchase, relevant information is available

Free experimentation of cleaning technology

Free equipment configuration and equipment installation

Free training for your technical and operational staff

Provide timely, efficient supply of spare parts accessories to all users.

# Company information:

Skymen Cleaning Equipment Shenzhen Co. Ltd., that has worked on ultrasonic cleaner for more than 8 years.

Our ultrasonic products fully range from mini household ultrasonic cleaner, benchtop stainless steel small ultrasonic cleaner, and industrial large tank ultrasonic cleaner as well as Immersible ultrasonic transducer system.

Our company devote to research and development, with strong engineer teams.

Otherwise, we accept customer's idea and want to develop new products together.



## **Skymen Technology Corporation Limited**



86-755-27094405



info@skymen.cc



skymenultrasonic.com