

100 Liter Boiling 100°C Kitchen Soak Tank 2mm Thickness For Instruments

Basic Information

Place of Origin: China
Brand Name: SKYMEN
Certification: CE, RoHs, FCC
Model Number: JP-98LZF

Minimum Order Quantity: 1

Price: Negotiation Packaging Details: wooden case Delivery Time: In Stock

• Supply Ability: 1000 pcs per month



Product Specification

Application: Medical Instruments

Temperature Control: 20~100 °C
Thermal Insulation: Available
Tank Capacity: 98L
Heating Power: 6000W

Tank Dimension: 800(L) * 350 (W) * 350 (H)mm
 Highlight: 100 Liter Kitchen Soak Tank, Boiling 100°C Kitchen Soak Tank,

2mm Thickness Ultrasonic Cleaning Tank



More Images



Product Description

Boiling Bath 100°C Cleaning for Surgical Instruments 100 Liter Soaking Tank

FEATURES

- Machine Type: Boiling tank
 Boiling water Cleaning
- 3. Cleaning Type: Immersion / Soak
- 4. Saving labor; time; detergent
- 5. SUS 304/SUS 316 tank material
- 6. Castor Wheel: with brake
- 7. Liquid level switch can be added
- 8. Heater: room temp-100°C Adjustable
- 9. Thermal insulation
- 10. With water inlet/out let in suitable place
- 11. Lid hinged to machine
- 12. Have a lift points in the inside of the tank
- 13. Electronic Box
- 14. Basket to hold cleaning objects

JP-98LZF		
Boiling water cleaning		
SUS 304 (SUS 316 can be customized)		
2mm		
800*350*350MM		
940*680*800MM		
1040*780*900MM		
130KG		
98 Liter / 26 Gallon		
Stainless steel heating plate		
6000W		
Available		
1~99 minutes		
Room temperature ~ 100°C / 212°F adjustable		
On the bottom of inner tank		
Yes		
Yes		
150KG		
380V / 220V		
1 year		
CE; RoHS; FCC; REACH		
20 Working days		

Directions for use

Step



Fill the with (preferably hot) water to the 'Fill Line' marked on the inside, plug the tank into an electrical outlet, and switch ON

Step 2



Slowly add the oil/Carbon-Removal Powder

Step 3



Load the tank with your dirty pots, pans, vent hood filters into the tank and Close the lid, leaving the items in the tank to soak, and walk away!

Step



Remove the items from the tank, then simply rinse off any loose or softened carbon fragments.

APPLICATION

 Restaurants: pot, dishes, pan, grills, hood filters furnace, chopstick, fork, spoon, etc.
 Bakery shops: oven trays, bakeware, bakery pans, kettle 3 Hotel:

towel, bed sheet, tea ware, strainer

4. Beauty Salon:

cups, eyebrow tweezers, eyebrow clamps scissor, Embroidered eyebrow pencil

threading clip

5. Lab, Medical, hospital 6.Food production facilities

Model	Volume	Inner tank size	Unit size	Power supply	Heating power
	(L)	(MM)	(MM)	(V)	(KW)
JP-35LZF	35L	600*250*250	850*500*800	110/220V	3KW
JP-50LZF	50L	800*250*250	1050*500*800	110/220V	3KW
JP-72LZF	72L	600*300*400	850*550*900	220/380V	6KW
JP-98LZF	98L	800*350*350	1050*600*900	220/380V	6KW
JP-128LZF	128L	800*400*400	1050*650*900	220/380V	6KW
JP-160LZF	160L	800*500*400	1050*750*900	220/380V	6KW

Packing & Delivery

Company Profile

Skymen Cleaning Equipment Shenzhen Co. Ltd., that has worked on ultrasonic cleaner for more than 13 years. Our ultrasonic products fully range from mini household ultrasonic cleaner, benchtop stainless steel small ultrasonic cleaner, and industrial large tank ultrasonic cleaner as well as Immersible ultrasonic transducer system. Our company devote to research and development, with strong engineer teams. Otherwise, we accept customer's idea and want to develop new products together.

Skymen Boiling Bath

Boiling disinfection method-method steps 1 Items should be washed before disinfection. Wrap fragile items with gauze and put them in the water to prevent them from colliding with each other when boiling. Impermeable items, such as plates and bowls, should be placed vertically to facilitate the convection of water. The water surface should be higher than the object. The sterilizer should be covered. 2. When disinfecting, the time should be calculated after the water boils. Generally, it takes 15 to 20 minutes to boil the contaminated equipment and articles of patients with hepatitis for 30 minutes. When sterilizing syringes or surgical instruments, they should be boiled for 30-40 minutes. Adding 2% sodium carbonate can prevent rust and increase the boiling point (1% sodium carbonate is added to the water, the boiling point can reach 100 °C), and the death of microorganisms can be accelerated. 3. When boiling and disinfecting cotton fabrics, it is not advisable to place too many items at a time. When boiling, stir slightly to aid convection of water. When more items are added, the boiling time should be extended to more than 30 minutes. 4. When disinfecting, do not store air bubbles between items; do not put in substances that can increase viscosity. During the disinfection process, the water should be continuously boiled, and no new contaminated items should be added in the middle, otherwise the disinfection time should be recalculated after the water boils again. 5. During disinfection, because the items have no outer packaging, be careful to prevent re-contamination when they are taken out and placed afterwards. For sterilized unpackaged medical equipment, the requirements for aseptic operation should be strictly followed when taking and storing them. (end)



Skymen Technology Corporation Limited



86-755-27094405



info@skymen.cc



skymenultrasonic.com

Floor 1st & 2nd, Building 3, Tanggang Taifeng Industrial Park, Dawangshan Community, Shajing Street, Bao'an District, Shenzhen